

**Maintenance:**

The surface of the sphere and monitor screens should be occasionally dusted off and the orbital speed empirically readjusted if needed.

**Daily Operations:****Start up:**  
-----

1. Turn on power on all monitors, cameras and motors (central switch)
2. Verify that the installation goes into motion and displays video on the monitors.

**Shut down:**  
-----

Turn off power on all devices

*Best Regards*  
*Stein*